Aerodynamic Fin Installation Instructions



WARNING

- Once the aerodynamic fin is installed, it is difficult to remove, if removed forcefully it may break.
- Be sure which fin set you would like to install, the 3M sticky backing is pressure sensitive adhesive and bonds on contact.

Aero fin removal instructions



- Air blade fin caps removal

 Remove the black plastic Nitto Denko caps with the internal rubber sleeve.





- (B) Air blade fin removal
 - 2 Holding the lamp, firmly apply even pressure on both shafts.

Note: You can apply pressure using a thumb on either shaft with the lamp laying flat and the serial no. showing on the top side.






Aero fin installation instructions



- Air blade fin

- Remove the red film liner from sticky pad backing.
- 2. Mount the fin on the lamp, pressing firmly on the top and bottom until contact with surface.



Tip: Mount the fin first without removing the sticky pad red film to test fitment.

- (D) Rubber sealing caps
 - Apply direct force, pressing the caps down on either shaft

Note: you can use a drop of dish detergent on the shaft for ease of installation.

